
17.32
[440]
15.55
[395]
PUSH FOR TICKET
ASSISTANCE
INSERT CARD
WAIT FOR PROMPT TO REMOVE
INSERT CARD
WAIT FOR PROMPT TO REMOVE
18.35
[466]
CARDS ONLY
WAIT FOR PROMPT TO REMOVE
VISA
MasterCard
AMERICAN EXPRESS Card
DISCOVER
50.24
[1276]
37.87
[961]
29.13
[740]
2.75
[70]
ACCEPTING CARDS ONLY
VISA
MasterCard
AMERICAN EXPRESS Card
DISCOVER
DRIVE UP
Pay Here
CARDS ONLY
VISA
MasterCard
AMERICAN EXPRESS Card
DISCOVER